




CHQ-BS - Programming Lead Instructions

General Description

The enclosed lead must be used for addressing CHQ-BS if they are selected as Wall Sounders.



Operation-Address Setting

To program a CHQ-BS connect the black croc clips to the left hand terminal on the TCH-B100 address programmer and to the C terminal of the Base Sounder and the red croc clips to the right hand terminal of the TCH-B100 address programmer and to the L terminal on the Base Sounder. The address can now be programmed in the same way as an ASX range sensor. **Please note that when programming CHQ-BS the maximum address permissible is 254. CHQ-BS/Control Panel instructions should be checked for address range.**

Caution

- Only to be used with Hochiki Loop devices.
- Do not short croc clips together.
- Remove from programmer when not in use.
- Disconnect Sounders from the loop before programming.

CHQ-BS PROGRAMMING LEAD - PL1



World Class Leaders in Fire Detection
for over 80 years

**Hochiki Europe (UK) Limited, Grosvenor Road,
Gillingham Business Park, Gillingham, Kent, ME8 0SA.
Telephone: 01634-260133 Facsimilie: 01634-260132
E-mail : Sales@hochikieurope.com**

U.K Manufactured Product